


Date Watch




Date Setting

1. Pull the crown out to position 2.
2. Turn the crown either clockwise or counter-clockwise and set the date for the previous day. The direction that moves the date varies on different watch models.

Time Setting

1. Pull the crown out to position 3.
2. Turn the crown counter-clockwise to advance the time and continue until the day changes to the present day.
3. Set to the correct time.
4. Push crown back to position 1.

Modelos con Calendario




Ajuste de Fecha

1. Tire de la corona a la posición 2.
2. Gire la corona y fije la fecha del día anterior. La dirección en que se mueve la fecha varía en los distintos modelos de relojes.

Ajuste de la Hora

1. Tire de la corona a la posición 3.
2. Gire la corona para hacer avanzar la hora y continúe hasta que cambie la fecha a la del día vigente.
3. Fije la hora correcta.
4. Oprima la corona a la posición 1.

Modèles avec Indication de la Date



Réglage de la Date

1. Tirez la couronne en position 2.
2. Tournez-la soit dans le sens des aiguilles, soit dans le sens contraire, puis réglez à la date du jour précédent. Suivant les modèles, le sens qui fait avancer la date est différent.

Réglage de l'Heure

1. Tirez la couronne en position 3.
2. Tournez dans le sens inverse des aiguilles pour mettre à l'heure et continuez jusqu'à ce que l'indication du jour passe à celui du moment.
3. Mettez à l'heure exacte.
4. Repoussez la couronne en position 1.